YOW SKU # 576 760

Model # TY169-1218

USE AND CARE GUIDE

6 FT LED TWIG TREE

THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 6 FT LED TWIG TREE. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

Guarantee

What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

1-877-527-0313

HOMEACCENTSHOLIDAY.COM

Pre-Assembly

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return to store. Assembly of this product may require more than one person.

PACKAGE CONTENTS



Package Contents/Parts List		
Part	Description	Quantity
A	Top of the tree	1
B	Upper half of the tree	1
C	Lower half of the tree	1
D	Stake	4
E	"S" Hook with string	4
F	Driving Cap	1
G	Screw	4

Package Contents/Parts List		
Part	Description	Quantity
H	Pole	1
I	Wing nut/bolt	2
J	Tree Stand	2
K	Pole Ground Stake	1
L	Fuse	1
M	Replacement Bulbs	2

Assembly

Assembling the Tree



Step 1. Align the inner piece and outer piece of Tree Stand (J) to fit together. Insert the short Pole (H) into the center tube of Tree Stand. Fasten them with the pre-attached Screws (G). Fig.1
Step 2. Place the Lower half of the Tree pole (C) into the upper end of short pole in Tree Stand and tighten them together with the Wing Nut/Bolt (I). Fig.1
Step 3. Place the Upper half of the Tree (B) onto the Lower half and tighten them together with the Wing Nut/Bolt (I).
Step 4. Place the Tree Top into the Top of the Tree (A). Fig.1
Step 5. The branches are pre-bundled. Gently pull the branches apart. Make sure the inner end of each main branch is properly secured in the hook on the pole.
Step 6. Gently pull the mini branches apart to form a fully extended tree shape. Fig.1

Assembling the Tree and Securing to Ground



Step 1. Place the Driving Cap (F) on the top of the Long sharp end Pole Ground Stake (K) and drive into the ground. Remove the cap. Fig.2
Step 2. Repeat Step for indoor use step 1.Then put the tree stand onto the Long Pole stake. Repeat Step for indoor use step 2-6. Fig.3
Step 3. Each anchoring string provided has a "S" Hook (E) at one end. Tie up the free end to the ground stake. Evenly attach each "S" hook of four strings to the root of each cluster of branches approx. 3/4 length up the Tree as shown in Fig.3.
Step 4. Pull the String tight and drive the Ground Stake (D) at the other end into the ground to secure the Tree. Fig.3

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 33.6 Watts (0.28Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
b. Wipe the unit with a damp cloth and allow the unit to dry before storing.
c. Store the product neatly in a cool, dry location protected from sunlight.

FOR INDOOR AND OUTDOOR USE